



ISLAND PADS  
INFLATABLE ISLANDS

ISLAND SUP  
INFLATABLE PADDLEBOARDS



sales@islandproductscanada.ca  
6435 Highway 89 E, Alliston, On. L9R 1V2

---

## **INCLUDED WITH YOUR DOG RAMP**

**Manual Pump - Repair Patches**

**Inflatable Structure - Mesh Ramp**

**D-Rings working load limit of 150 Lbs - Mesh working load limit of 150 Lbs**

**- Max Inflation 5PSI**

**Not Intended to be left in the sun for over 31 consecutive days**

## **RAMP INSTALLATION**

**ASSEMBLY:** Your Island Dog Ramp MAY require the mesh ramp to be attached to the inflatable. Inflate the yellow tube and place it on a flat surface right side up, lay the mesh so the three grip strips are facing up. Flip over both pieces and thread the bungee shock cord through the loops. Pull slight tension and tie the shock cord back on itself once fully threaded. Left over may be cut off. ( Photo for reference are included on page 4 )

## **HOW TO USE**

**SETUP:** Your Island Dog Ramp is designed to float off your swim platform or Island Pad, it can be tied fairly tight to the boat or Island pad with the top D-rings.

We have tested the Island Dog Ramp with over 20 different dogs (all sizes and breeds) and they are all successful after a couple uses and proper training.

Training your dog will require consistent encouragement but will become easy after a couple uses. It is best to install your dog ramp in the same position every time to keep you dog familiar with its location.

Doggie Life Vests **DO NOT** help the dog when using the ramp but rather get in the way of the dog lifting its rear legs enough to enter the ramp.

You may find the first couple uses your dog's rear legs get caught on the mesh, allow your dog to figure out that they have to lift their legs high enough over time this will become second nature.

## **GENERAL USE**

**INFLATION:** Your Island Dog Ramp can be inflated to 5 PSI (max tested PSI 6).

When inflating with a manual pump you may find the last 20-30 pumps to be fairly difficult, but are required to get your Island Dog Ramp to full inflation.

*NOTE:* Adding air on cool days may be necessary prior to using your Island Dog Ramp.

**MANUAL PUMP:** The manual pump will inflate your Island Pad to 5 PSI after approximately 5 minutes of constant pumping.

**OPTIONAL ELECTRIC PUMP:** The optional 110V pump works to inflate and deflate your Island Dog Ramp. This is easily accomplished by screwing the hose into the "in" or "out" side of your pump. Your pump is designed to blow air through the switch and cord hole as well as the breather holes around the "in" side, this is to allow the motor to be cooled even if it is not pumping air into your Island Dog Ramp due to from a fully inflated Dog Ramp, blockage or similar.

**AIR VALVE OPERATION:** The inflation valve operates in 2 positions. 1.) In the closed/fill position the valve stem (white button) will appear raised. This allows you to inflate the Island Pad and remove the hose without losing air. 2.) Press the valve stem (white button) down to release air. Then press the valve stem (white button) again to return the inflation valve to its closed/ fill position.

Note: You can leave your Island Dog Ramp inflated while it's stored! It's not necessary to inflate and deflate after each use unless being transported or stored in small spaces, or being exposed to high temperatures (see *Precautions & Guidelines* on next page for more information).

**AIR COMPRESSOR:** Use of an air compressor to inflate the Island Dog Ramp will VOID your 2-year warranty. Air compressors can easily overinflate your Island Dog Ramp without warning, causing it to burst.

**DEFLATION:** Ensure the valve area is dry so water doesn't become trapped inside your Island Dog Ramp when opening the inflation valve. Press down on the valve stem (white or Grey button) to lock the valve in the open/deflate position. Once the valve stem is down, air will escape. Fold your Island Dog Ramp and roll it up from the opposite end the fill valve is located on (like a sleeping bag!) and force the air to run out of the valve if you didn't use the pump to suck it out. Once all the air is out, push down the valve stem again so it locks in the closed/fill position. Once it's in the closed/fill position, air will no longer be able to escape or enter the Island Dog Ramp (unless you attach the pump and force it in).

## **PRECAUTIONS & GUIDELINES**

**LEAVING YOUR ISLAND DOG RAMP INFLATED:** You can leave your Island Dog Ramp inflated! You only need to deflate your Island Pad when transport or storage in small spaces is required.

Note: Keeping your Island Dog Ramp inflated for months at a time will result in it slowly releasing air. For example, leaving your Island Dog Ramp inflated for 1-2 months may cause it to lose 1-2 PSI s worth of air. Re-inflate to working air pressure before using for best results.

**EXTREME HEAT DAMAGE:** Allowing your Island Dog Ramp to be exposed to extreme heat *while inflated* may cause damage. Inflating your Island Dog Ramp to operating pressure and allowing it to reach extreme temperatures – (including but not limited to storage inside your car during summer months) – may cause the seams to burst. This type of damage is NOT covered under warranty.

**STORAGE:** Ideal storage is in a covered, temperature-controlled room. Constant sun exposure over summer months is damaging to your Island Dog Ramp and will cause premature fading and possible failure. Be sure to store your Island Dog Ramp out of the sun while not in use and wait for it to fully dry before rolling it up and storing.

You can keep your Island Dog Ramp rolled up when you aren't using it. We highly recommend storing your Island Dog Ramp indoors. Cold weather will not shorten the lifespan, but do not move the board if the weather is below 0 deg C (32deg F) as the PVC may crack in cold weather. Note you can store your Island Dog Ramp inflated or deflated.

**PATCHING:** The patch kit includes two patches, one for the top and one for the sides. Glue is not included in the patch kit as it may go bad before you use it. Flexible vinyl / PVC glue is available from most hardware stores or marinas that sell inflatable boat accessories. We recommend cutting your patches into large coin sized pieces for best patching results. Patch only when the pad is fully deflated and the area of repair is flat

- 1: Clean the surface with acetone around the puncture and also the back side of the patch you will be gluing down.
- 2: Apply an even layer of glue onto the back of the entire patch as well as the area on the pad that punctured
- 3: Push the patch onto the surface with pressure starting from the middle and working your way towards the outsides of the patch, clean up any extra glue prior to drying with Acetone. and keep constant pressure until dry.
- 4: Allow 24 Hours for glue to cure before inflation.

**Two Year Limited Warranty**

**WARRANTY COVERAGE**

Island Products Canada hereby warrants that the product is free of any defect in material and workmanship. The period of warranty is One Year from the date of purchase. So the warranty expires 730 days after the bill of sale is issued from the Dealer. If you notice any defect in the parts that are covered by this warranty, within the above said period, we will repair or replace it. Should we deem your Island Pad beyond repair, we will provide you with a free replacement.

**EXCLUSIONS:**

Island Products Canada will not have any liability or obligation under this limited warranty, in case of,

- 1.Any defect caused by misuse or abuse of the product.
- 2.Damage caused by natural disasters or neglect.
- 3.Damage caused by unauthorised modification or improperly installed accessories.
- 4.Defects caused by storage of the product in unsuitable environments such as moldy areas, against an abrasive surface or in a high heat environment.
5. The warranty does not apply to cosmetic damage such as scratches or general wear for daily use or chemical stains from improper cleaning or animal droppings.

**LIMITATIONS:**

The only recourse to you, in case of any defect in the product, is repair or replacement of the parts, as specified above. We will not be liable for any consequential damages or inability to use the product. The cost of the repair or replacement shall not be higher than the purchase price of the product, excluding tax, shipping, and installation charges.

By using the product, the user accepts the terms and conditions described herein.

**WARRANTY SERVICE:**

For warranty service or inquiries please submit any photos of the damaged area, with a copy of the bill of sale to [Sales@Islandproductscanada.ca](mailto:Sales@Islandproductscanada.ca) with the title reading "Warranty"

*Please include all relevant contact information for our team to reach you at.*

